DE

Geeignet für 2 x 1,5 V Batterie vom Typ AA (Nicht im Lieferumfang enthalten).
Öffnen Sie das Batteriefach. Legen Sie die Batterien ein. Achten Sie dabei auf die korrekte Polarität (+/-).
Zum Einschalten schieben Sie den Schalter auf ON.
Vorsicht mit Batterien! Ausgelaufene Batteriesäure kann zu Verätzungen führen. Vermeiden Sie den Kontakt von Batteriesäure mit Haut, Augen sowie Schleimhäuten. Bei Kontakt mit Batteriesäure umgehend die betroffenen Stellen mit reichlich klarem Wasser spülen und gegebenenfalls den Arzt aufsuchen. Batterien (insbesondere Lithiumbatterien) können bei unsachgemässer Handhabung explodieren. Versuchen Sie niemals, Batterien zu laden. Setzen Sie nur Batterien desselben oder gleichwertigen Typs ein. Batterien und Akkus dürfen Sie nicht erhitzen, kurzschließen oder durch Verbrennen beseitigen. Nicht direkter Sonneneinstrahlung aussetzen.
Altgeräte dürfen nicht in den Hausmüll! Sollte das Produkt einmal nicht mehr benutzt werden können, so ist jeder Verbraucher gesetzlich verpflichtet, Altgeräte getrennt vom Hausmüll zu entsorgen und z.B. bei einer Sammelstelle seiner Gemeinde/ seines Stadtteils abzugeben. Elektroaltgeräte werden dort kostenlos angenommen. Damit wird gewährleistet, dass die Altgeräte fachgerecht verwertet und negative Auswirkungen auf die Umwelt vermieden werden. **Batterien und Akkus dürfen nicht in den Hausmüll!** Als Verbraucher sind Sie gesetzlich verpflichtet, alle Batterien und Akkus, egal ob sie Schadstoffe* enthalten oder nicht, bei einer Sammelstelle in Ihrer Gemeinde/Ihrem Stadtteil oder im Handel abzugeben, damit sie einer umweltschonenden Entsorgung zugeführt werden können. **gekennzeichnet mit Cd = Cadmium, Hg = Quecksilber, Pb = Blei*
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

DE

Geeignet für 2 x 1,5 V Batterie vom Typ AA (Nicht im Lieferumfang enthalten).
Öffnen Sie das Batteriefach. Legen Sie die Batterien ein. Achten Sie dabei auf die korrekte Polarität (+/-).
Zum Einschalten schieben Sie den Schalter auf ON.
Vorsicht mit Batterien! Ausgelaufene Batteriesäure kann zu Verätzungen führen. Vermeiden Sie den Kontakt von Batteriesäure mit Haut, Augen sowie Schleimhäuten. Bei Kontakt mit Batteriesäure umgehend die betroffenen Stellen mit reichlich klarem Wasser spülen und gegebenenfalls den Arzt aufsuchen. Batterien (insbesondere Lithiumbatterien) können bei unsachgemässer Handhabung explodieren. Versuchen Sie niemals, Batterien zu laden. Setzen Sie nur Batterien desselben oder gleichwertigen Typs ein. Batterien und Akkus dürfen Sie nicht erhitzen, kurzschließen oder durch Verbrennen beseitigen. Nicht direkter Sonneneinstrahlung aussetzen.
Altgeräte dürfen nicht in den Hausmüll! Sollte das Produkt einmal nicht mehr benutzt werden können, so ist jeder Verbraucher gesetzlich verpflichtet, Altgeräte getrennt vom Hausmüll zu entsorgen und z.B. bei einer Sammelstelle seiner Gemeinde/ seines Stadtteils abzugeben. Elektroaltgeräte werden dort kostenlos angenommen. Damit wird gewährleistet, dass die Altgeräte fachgerecht verwertet und negative Auswirkungen auf die Umwelt vermieden werden. **Batterien und Akkus dürfen nicht in den Hausmüll!** Als Verbraucher sind Sie gesetzlich verpflichtet, alle Batterien und Akkus, egal ob sie Schadstoffe* enthalten oder nicht, bei einer Sammelstelle in Ihrer Gemeinde/Ihrem Stadtteil oder im Handel abzugeben, damit sie einer umweltschonenden Entsorgung zugeführt werden können. **gekennzeichnet mit Cd = Cadmium, Hg = Quecksilber, Pb = Blei*
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de

GB

Suitable for 2 x 1.5 V AA batteries (not included).
Open the battery compartment. Insert the batteries. Make sure the polarity (+/-) is correct.
To turn on, slide the switch to ON
Be careful with batteries! Leaking battery acid can cause chemical burns. Avoid contact of battery acid with skin, eyes and mucous membranes. If you come into contact with battery acid, immediately rinse the affected areas with plenty of clean water and seek medical attention if necessary. Batteries (especially lithium batteries) can explode if handled improperly. Never try to charge batteries. Only use batteries of the same or equivalent type. Batteries must not be heated, short-circuited or disposed of by burning. Do not expose them to direct sunlight. **Old devices must not be disposed of in household waste**!
If the product can no longer be used, every consumer is legally obliged to dispose of old devices separately from household waste and, for example, to hand them in at a collection point in their community/district. Old electrical devices are accepted there free of charge. This ensures that old devices are properly recycled and negative effects on the environment are avoided. **Batteries and rechargeable batteries must not be disposed of in household waste!** As a consumer, you are legally obliged to hand in all batteries and rechargeable batteries, regardless of whether they contain harmful substances* or not, to a collection point in your community/district or to a retailer so that they can be disposed of in an environmentally friendly manner.
*marked with Cd = cadmium, Hg = mercury, Pb = lead
HDC Heim Decor GmbH Mühlenweg 144 22844 Norderstedt support@Heim-Decor.de